



0-10V Controller and Ballast Communication



Definition for controller and ballast connection RJ14